

Table of Contents:

• Product Description.....	2
• Product Overview.....	2
• Charging.....	2
a. Car charger/USB Charger.....	2
b. Solar Charging.....	3
• Mounting the auto-talk.....	3
• Pairing the auto-talk to a cell phone.....	3-4
• Transmitting range of the auto-talk.....	4
• Basic Functions.....	4-5
• Text-to-speech.....	5
• Using the phonebook application.....	5-6
• Product specifications.....	6
• Safety information.....	6
• Declaration of conformity.....	6-7
• Warranty.....	7
• Technical Support.....	7

Product Description

The BluBridge auto-talk is a sleek, solar powered, Bluetooth Speakerphone designed for automobile use. The auto-talk wirelessly connects with your mobile phone allowing you to make and receive calls hands-free. Built-in echo cancellation and noise suppression technology allows for crystal clear conversations even in noisy environments.

Product Overview

1. Phone button
2. Micro USB charging port
3. LED light
4. Volume down (-)
5. Volume up (+)
6. Speaker
7. Mute button
8. Microphone
9. Solar panel



Charging

The auto-talk charges automatically in the presence of sunlight using its solar panel. But for cloudy days and night-time use, the auto-talk can be charged with the included USB cable and car adapter. Simply plug the cable into the auto-talk's micro USB port (2) and connect to the car charger or a PC.

Before first use, charge the device via the car charger or USB charging cable for 3.5 hours or with the solar panel for 18 hours to ensure that the battery reaches its full capacity.

Car charger/USB charging cable

- Plug the included car charger into a 12v power outlet; attach the USB cable to the charger and to the auto-talk.
- After the first charge each additional charge cycle will take approximately three hours.
- The auto-talk's LED light (3) will glow red when charging is in progress and will turn off when charging is complete. A full charge will provide about 13 hours of talk time.
- If the auto-talk has not been in use for several months, the LED light(3) may take 15-30 minutes to turn on once the auto-talk is plugged in.

Solar charging

- Angle the solar panel (located on the back of the auto-talk) towards sunlight.
- LED light (3) will glow red when solar charging is in progress.
- The solar charger operates on a 2:1 ratio, meaning that if the auto-talk receives continuous sunlight for two hours, the battery will provide one hour of talk time. If the auto-talk remains in sunlight, the battery will continue to charge (even while in use), increasing the auto-talk's talk and standby time exponentially.

Mounting the auto-talk

Slide the auto-talk into the suction cup mounting system. The auto-talk can be mounted to windshields, dashboards or any clean, flat surface. Before installing, clean mounting surface with glass or all-purpose cleaner; slightly moisten suction cups with water and press device firmly and evenly against surface.

Make sure to check local guidelines before mounting the device to a windshield. Recommended mounting spots include: the upper left corner of the windshield and the center of the windshield above the rearview mirror with the microphone pointed towards the driver. Before installation, check if these positions are in accordance with local regulations for windshield mounted devices.

When mounting on a dashboard, do not place the auto-talk over or in the direct path of air vents, as it could cause device to overheat. Solar charging may not occur while the auto-talk is mounted on a dashboard. The LED light (3) will indicate if the auto-talk is charging.

To remove auto-talk, gently pry up suction cups and pull device away from surface.

Pairing the auto-talk to a cell phone

Before initial use, the auto-talk must be paired with the user's cell phone by following the steps below:

1. Turn auto-talk off
2. Press and hold the phone button (1) for six seconds until the LED light (3) flashes red. A voice announcement will indicate that the auto-talk is in pairing mode.
3. Turn the cell phone's Bluetooth feature on and search for devices in range.
4. Select "BluBridge auto-talk" from the list of found devices on the cell phone and enter pin code/pass code 0000. A voice announcement will indicate "pairing successful" when devices have been paired.
5. Select "connect to auto-talk" on the mobile phone, if prompted. The announcement "phone is ready for use" will follow a successful connection.

If pairing fails, turn off the auto-talk and the cell phone's Bluetooth function and repeat above steps. To preserve battery life, the auto-talk will turn off automatically if a connection is not established within ten minutes.

Once a device is paired with the auto-talk, reconnection will happen automatically whenever the auto-talk is on and the mobile phone's Bluetooth setting is enabled.

Transmitting range of auto-talk

The auto-talk is a class 2 Bluetooth device, meaning that it has an operating range of 33 feet (10 meters). To ensure a stable connection, keep the cell phone and auto-talk within range of one another. If connection drops or becomes unstable, move the devices closer together.

Basic Functions

Function	From	Button	Hold	Indicator
Turn on	Off	Phone button (1)	4 seconds	Short beep; "Power on" announcement; LED (3) turns orange
Turn off	On	Phone button (1)	4 seconds	Beep; "Power off" announcement; LED (3) turns red
Answer a call		Phone button (1)	Press briefly	
End a call		Phone button (1)	Press briefly	
Re-dial last number		Phone button (1)	Press twice	
Reject a call		Phone button (1)	3 seconds	
Mute/unmute microphone	Mute/unmuted	Mute button (7)	3 seconds	LED (3) turns orange in mute mode and turns off when not muted
Hold a call/resume a call	During conversation	Phone button (1)	Press twice	

Answering a second call:

If while on a call a second call is received, press the phone button (1) briefly to hold the first call and answer the incoming call; press phone button (1) twice to end the second call and resume the first call.

Transfer a Call:

1. From the auto-talk to a mobile phone: press the mute button (7) twice.
2. From a mobile phone to the auto-talk: press the phone button (1) briefly.

Voice Dialing:

If your phone supports voice dialing, follow your cell phone manual's instructions for set up. Once established, to access voice dialing on the auto-talk:

1. Press the phone button (1) briefly; you will hear a short beep.
2. Say the name of the person you wish to call.

Privacy Mode:

To keep others from overhearing a conversation, press the mute button (7) once during a call and the auto-talk's speaker volume will automatically be decreased to a minimum level.

Text-to-speech

1. Turning ON/OFF text-to-speech function: To turn text-to-speech on or off, hold the vol+ button (5) for 6 seconds while auto-talk is paired but no phone call is in progress; auto-talk will announce "voice prompt on" or "voice prompt off".
2. Select language: while auto-talk is paired but not in use, press the vol+ button (5) for 3 seconds until the orange LED light flashes 3 times and announces "select language." Languages are arranged as follows: English, French, Italian, German, and Spanish; auto-talk will say "select language" in each. To advance to the next language, press vol+ (5) for 3 seconds after each "select language" announcement until arriving at desired language.

Using the phonebook application

When text-to-speech is turned on, the auto-talk will automatically announce the phone number of an incoming caller. Transferring your mobile phone's phonebook to the auto-talk enables the auto-talk to announce the name of the incoming caller in place of the number.

To transfer a mobile phone's phonebook to the auto-talk, use the following steps:

1. When paired to a mobile phone but not on a call, press and hold the mute button for 3 seconds. The auto-talk will announce "Loading phonebook, please wait"; the LED indicator will turn on and remain lit during phonebook transfer.
2. During phonebook transfer, auto-talk will announce "please wait" every 30 seconds. Transfer is complete when "contact saved" followed by number of transferred phonebook entries is announced. The LED light will turn off.

3. Phonebook data is now saved in the auto-talk. To update the auto-talk's phonebook, repeat the transfer process.
4. Phonebook data saved in the auto-talk will be erased automatically when it is paired with a different mobile phone.
5. To remove phonebook entries hold down both vol+ and vol- buttons for 3 seconds. "Phonebook deleted" will be announced.

Product Specifications

- Bluetooth: Bluetooth v2.1 +EDR
 - Operating Frequency Band: 2.4 GHz~2.48GHz unlicensed ISM band
 - Output power: class 2, up to 33 ft (10 meters)
 - Support profiles: HSP, HFP 1.5 profiles
 - TTS support languages: English, French, Italian, German, Spanish
 - Integrated phonebook stores up to 1000 contacts
 - Supports multiple paired devices: memorizes paired data of up to 8 Bluetooth phones
 - Stand-by time: up to 450 hours*
 - Talk time: up to 13 hours*
 - Battery charging time: 3 hours with charger, 18 hours with solar power (time may vary depending on amount of available sunlight)
 - Charger voltage: DC5.0v, 400mA
 - Battery: 3.7V 550mA, (rechargeable lithium-ion battery)
- * Talk and standby times may vary depending on model of phone, usage settings, usage styles and environments.

Safety Information

- Do not drop the device
- Keep the device away from moisture and liquids; the auto-talk is not waterproof
- Do not dismantle auto-talk; doing so could cause injury and will void warranty
- Avoid exposure to extreme heat (120°F/48°C) or cold (0°F/-17°C)
- Use only supplied chargers to charge auto-talk

Declaration of conformity

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference and must accept any interference received, including interference that may cause undesired operation.
- The manufacturer is not responsible for ANY interference (for example radio or TV interference) caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.
- This product is CE certified according to the provision of the R&TTE Directive (99/5/EC).
- This product is declared to be in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC/.

Warranty

The conditions of this warranty and the manufacturer's responsibilities under this warranty are as follows:

- Warranty period is 1 year on parts and 90 days on the battery.
- The Warranty is non-transferable and is limited to the original purchaser only.
- Dated receipt must be provided.
- The warranty is void if the product has been subjected to physical abuse, improper installation, or modification and repair by an unauthorized third party.
- The responsibility of supplier's products shall be limited to the repair or replacement of the product at its sole discretion.
- Specifically exempt from any warranty are limited-life consumable components subject to normal wear and tear, such as batteries and other accessories.
- Supplier will not take any responsibility if the failure of the unit has resulted from an accident, abuse, misuse, or any unauthorized repair, modification or disassembly.
- Modification and repair of the unit should be done by an authorized and qualified service center, or unit should be returned to the manufacturer.
- Contact www.miccus.com for further details.

Technical support

For additional information about this product, online tutorials and technical support, please refer to www.miccus.com



www.miccus.com



©2009 Miccus, Inc. All rights reserved. iPod and iTunes are trademarks of Apple, Inc., registered in the U.S. and other countries. Bluetooth® is a registered trademark of the Bluetooth SIG, and used under license.



User Manual auto-talk